
USER GUIDE

The device offers the opportunity to play one of a number of audio recordings of 550 Squadron veterans.

Switch ON/OFF

	ON/OFF switch Switch ON: When device off. Press button (indicated) briefly. Red LED will come on. Green LED will flicker. [LEDs are situated at the lower left hand side, and too the rear, of the device.] Start-up takes up to one minute (to display of
F007348 BINO O	menu). Switch OFF: When device is already on and functioning (i.e. menu displayed on screen). Press ON/OFF button and hold for 1-2 seconds. Green LED will flicker. When the device shuts down safely it will power off and both LEDs will be extinguished.

Display Screen - Menu Selection



Audio Device

